

Sample Program for Windows

Published on July 2, 2020
Version 1.00

1. Table of contents

1.	1	
2.	2	
2-1.	Functions available	2
2-2.	Functions unavailable	2
2-3.	Controls on the camera	2
3.	3	
3-1.	Connecting	3
3-2.	Shooting still images	3
3-3.	Recording movies	3
3-4.	Using AF-S	3
3-5.	Using AF-C	3

2. Settings

Settings for the sample program.

2-1. Functions available

Functions available on the sample program are:

- Shutter speed
- Aperture
- ISO sensitivity (Auto / Manual)
- White balance
- Color mode

2-2. Functions unavailable

Functions not available on the sample program are:

- Shooting mode
 - M: Manual Exposure
- Shutter speed display
 - Shutter speed will be fixed
- Except for the above settings
 - The camera will be fixed on default settings

2-3. Controls on the camera

Controls on the camera:

- Aperture
 - Setting aperture using the aperture ring is given priority except for Auto mode
- Focus
 - Cannot use AF when MF is ON

No other buttons or dials are available to use.

3. Connecting and shooting

Connecting and shooting with the sample program.

3-1. Connecting

Enter the serial number of the camera in a text box at the top of the sample program, and connect the camera to your PC.

The serial number is displayed in the [SYSTEM] menu of your camera.

3-2. Shooting still images

Press the Still button to shoot a still image.

Still images can only be saved to your PC.

Still images are saved to your PC's Pictures folder with or without an SD card in the camera.

All still images are saved as JPEG files (FINE).

3-3. Recording movies

Press the Rec button to start video recording. The video recording will end after 10 seconds and the video recorded to the SD card will automatically be transferred to your PC.

The video file will be stored in the Pictures folder of the PC.

All videos are saved as MOV files (GOP).

As video files are recorded to the SD card before being transferred to your PC, video recording is not possible without an SD card in the camera.

3-4. Using AF-S

Press the AF-S button to perform AF-S operation once.

3-5. Using AF-C

Press the AF-C button to start AF-C operation. Press it again to end AF-C operation.